

---

**INSTALLATION INSTRUCTION - SOLBVHALO-FX5 Medium security baseplated to existing slab.**

---

Included in the kit;

- 3 x M8\*65mm stainless steel dynabolts,

The installation guide below assumes the existing slab is in good repair slab is level. If the slab is not level arrangements to ensure the solar bollard is installed plumb will need to be made. Contact us if this is the case, we're happy to offer some advice.

1. Mark, and using a depth guide drill a 8mm x 70mm deep hole in the existing concrete slab
2. Place the "HALO" Vandal Resistant Bollard over the fixing points
3. Insert and gently tap the dynabolts into place, ensure the bollards stem is level.
4. Tension dynabolts

Feel free to contact the office on the number below for any assistance with your install



M8 x 65mm dynabolts